






#### 1. Remove the Body







#### 2. Remove the Vehicle Battery




### 3. Charge the Vehicle Battery




# 4. Reinstall the Vehicle Battery




### 5. Install the Transmitter Batteries




## 6. Power On the Transmitter



### 7. Reinstall the body







### 8. Power On the Vehicle




### 9. Forward/Reverse






## 10. Steering







## 11. Steering Trim




## 12. Throttle Limiter




## 13. Steering Rate




### 14. Remove the Body






### 15. Power Off the Vehicle



# 16. Disconnect the Vehicle Battery



### 17. Power Off the Transmitter

