

# Minimum RC™


## Piper Cub J-3 Assembly Instructions



1.



2.



3.



4.



5. Fix steel landing gear with screw.



6. Use a ruler to push the crease along the dotted line. Glue the cockpit reinforcement part.



7.




MinimumRC

8.




MinimumRC

9.



10.





11.



MinimumRC

12.



MinimumRC

13.



14.





15.



16.



17.



18.



19.



 MinimumRC

20.



 MinimumRC

21.



22.



23.




24. When the balsa is too difficult to bend, wipe the outer surface with a wet cloth.



25.



26.





27. Install the hatch (not gluing it).



28. Sand the fuselage.



29.



MinimumRC

30.



MinimumRC

31. Make a hinge with tape.



32.



33.



34.



35.




MinimumRC

36.



MinimumRC

37.




38. Use heat shrinkable tube to hold the wheels.






39. Glue the windshield.



40.



41.



42. Assemble the dummy engines.



43.



44. Install the magnets.





45.




46. Installation of the control horns.



47.




48. Connect the pushrod clips & pushrods with heat shrinkable tube and fix them with glue.



49. Installation of the pushrods.



50.






51.



MinimumRC

52.




MinimumRC

53.



54.





Completion of assembly

---

#### First test flight

- The center of gravity is 10 mm from the leading edge of the wing. Move the battery forward and backward to adjust the center of gravity.
  - The amount of elevator, rudder are 5 mm for each side. Please adjust the rudder surface to the level before flight test.
- 

Explore the ultimate possibility of airplane kits

MinimumRC.COM