

Operating Instructions **JR ScanSelect Receivers**

Congratulations on the purchase of JR's latest offering in receiver technology.

General Operation

The operation of your new JR® ScanSelect™ Receiver is designed to be easy and user-friendly, allowing for maximum convenience for the user, whether at the flying field or workbench.

The ScanSelect receivers are designed to scan, detect and select the strongest operating signal when instructed to do so by the user.

Tx Compatibility –

The ScanSelect JR receivers are compatible with all JR transmitter types. Depending upon the receiver type (SPCM or FM), the transmission mode will need to be changed on the transmitter to match the receiver type.

Changing Operating Channels:

1. Turn the power switch of the transmitter to "On" and have the transmitter located very close to the receiver and/or airplane with the receiver installed.
2. Apply power to the receiver. The receiver LED should glow.
3. Using a small instrument, depress the "Scan" button until the receiver LED turns off, then release the button. The LED will remain off.
4. Depress the "Scan" button once again. The receiver LED will flash for a short period while the receiver scans for the strongest frequency. When the receiver has locked onto its new frequency, the receiver LED will return to a solid glow, indicating the receiver is ready for operation.
5. Your receiver will remain locked onto this new assigned frequency until you, the user, initiate this change sequence again.
6. Be sure to perform a range check following the instructions provided with your radio system before flying on the new frequency choice.

JR Product Warranty

Important Note: Be sure to keep your original, dated sales receipt in a safe place as you will be required to provide proof-of-purchase date for the equipment to be serviced under warranty.

WARRANTY COVERAGE

Your new JR Remote Control Radio System is warranted to the original purchaser against manufacturer defects in material and workmanship for 3 years from the date of purchase. During this period, HORIZON SERVICE CENTER will repair or replace, at our discretion, any component that is found to be factory defective, at no cost to the purchaser. This warranty is limited to the original purchaser of the unit and is not transferable. This warranty does not apply to any unit which has been improperly installed, mishandled, abused, or damaged in a crash, or to any unit which has been repaired or altered by any unauthorized agencies. Under no circumstances will the buyer be entitled to consequential or incidental damages. This limited warranty gives you specific legal rights; you also have other rights which may vary from state to state. As with all fine electronic equipment, do not subject your radio system to extreme temperatures, humidity or moisture. Do not leave it in direct sunlight for long periods of time.

REPAIR SERVICE DIRECTIONS

In the event that your JR radio needs service, please follow the instructions listed below:

1. Check all on/off switches to be sure they are off. This will speed the repair process of checking battery condition.
2. Return your system components only (transmitter, receiver, servos, etc.) Do not return your system installed in a model aircraft.
3. Preferably, use the original carton/packaging (molded foam container), or equivalent, to ship your system. Do not use the system carton itself as a shipping carton. You should package the system carton within a sturdy shipping container using additional packing material to safeguard against damage during transit. Include complete name and address information inside the carton, as well as clearly writing it on the outer label/return address area.
4. Include detailed information explaining your operation of the system and problem(s) encountered. Provide an itemized list of equipment enclosed and identify any particular area/function which may better assist our technicians in addressing your concerns. Date your correspondence, and be sure your complete name and address appear on this enclosure.
5. Include your name, mailing address, and a phone number where you can be reached during the business day.
6. Warranty Repairs. To receive warranty service, you must include your original, dated sales receipt to verify your proof-of-purchase date. Providing that warranty conditions have been met, your radio will be repaired without charge.
7. Normal Non-Warranty Repairs. Should your repair cost exceed 50% of the retail purchase cost, you will be provided with an estimate advising you of your options. Within your letter, advise us of the credit card you prefer to use. HORIZON SERVICE CENTER accepts VISA, MasterCard, American Express, or Discover. Please include your card number and expiration date. The HORIZON SERVICE CENTER also accepts money orders.

Mail your system to:
Horizon Service Center
4105 Fieldstone Road
Champaign, IL 61822
Phone: (217) 355-9511
www.horizonhobby.com